



All engines

**Note**

On engine 110 the nuts of the intake and exhaust manifold at the cylinder head need **no longer** be retightened because of their separate arrangement.

- Check all nuts or screws of intake pipe and exhaust manifold on cylinder head for tight fit and tighten, if required.



- Retighten bolts of exhaust flanged connections.

**Except flanged connections with spring pretension.**

